


GRS® BenchMate® QC Pin Vise

INSTRUCTIONS • #004-879






NOTE: Overtightening the jaws will cause wear and damage to the threads.

Replacement Parts List




Part #	Description	QTY
003-451	Steel Pin	4
003-452	Brass Pin	4
024-215	5 mm Hex Wrench	1

CHANGING QC FIXTURES

FIXTURE REMOVAL



QC PIN VISE INSTALLATION



⚠ WARNING
Make sure QuickChange fixture is seated fully before tightening with mandrel knob.
A fixture can be ejected with force if not properly seated when tightening.

GLEND0 LLC

900 Overlander Road • Emporia, KS 66801 USA
800-835-3519 • 620-343-1084 • Fax: 620-343-9640
grs@grstools.com • www.grstools.com
Last Updated: 2023/08/23

LIT-441